



Guía Proceso Pre-Tratamiento y Post-Tratamiento

Tipo Colorante: Pigmento DuPont™ Artistri™ Serie 700
Tipo Tejido: Algodón

Guía Proceso Pre-Tratamiento

No necesita pre-tratamiento.

Guía Proceso Post-Tratamiento

◆ Para tejidos de algodón ligeros (120 g/m²), se recomiendan las siguientes condiciones para obtener las máximas solidez:

Calandra: 190C, 1 min, 10 psi
Rame: 175C, 4 min

◆ Para tejidos de algodón gruesos (237 g/m²), se recomiendan las siguientes condiciones para obtener las máximas solidez:

Calandra: 190C, 1 min, 10 psi
Rame: 185C, 4 min

◆ Con base a los datos preliminares, se recomienda las siguientes condiciones para mezclas poliéster/algodón (35/65):

Calandra: 160C, **5 min***, 10 psi
Rame: 175C, 5 min

***Puede requerir múltiples pasos para conseguir el tiempo de polimerizado.**

The information has been carefully compiled from experience gained in the laboratory and under commercial conditions. However, the product's performance and its suitability for the customer's purpose depend on the particular conditions of use. We recommend that customers satisfy themselves that each product meets their requirements in all respects. This information is being provided by DuPont free of charge as a courtesy to DuPont's customers, and DuPont HEREBY DISCLAIMS ALL REPRESENTATIONS, WARRANTIES AND LIABILITIES WITH RESPECT TO THE INFORMATION AND USE THEREOF. Subject to change without notice. All sales are subject to our standard terms and conditions of sale.

DuPont Ink Jet · Barley Mill Plaza · PO Box 80030 · Wilmington, DE 19880-0030

Artistri.DuPont.com | **US** 1.877.234.1794 or 1.302.992.4264 | **Asia** 65.6586.3699 | **Europe** 39.02.2530.2657

© Copyright 2003. Rev. 2004. E.I. du Pont de Nemours and Company. All rights reserved. The DuPont Oval, DuPont™, The miracles of science™ and Artistri™ are registered trademarks or trademarks of DuPont or its affiliates.
K-04404-2 11/04



The miracles of science™